



Maxus Ceramics  
Wattstraat 19  
NL-3771 AG Barneveld  
Tel. 0342-413414  
[www.maxusceramics.com](http://www.maxusceramics.com)  
[info@maxusceramics.com](mailto:info@maxusceramics.com)

## Maxus Ceramics & Moeller Stone Care maintenance and cleaning advice

### Cleaning - Maintenance

Conditions: When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content). Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed. Drying times are indicative only and are subject to variation depending on the weather and the object. It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent. Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

### Cleaning:

You can remove the cement veil and the construction waste approximately 48 hours after the surface has been laid. Before cleaning, make sure that the joints are wet. To remove the soiled dirt and to get the floor "stain free" again, clean the entire floor with HMK R157 Intensive tile cleaner. Mix 1:10 with water, soak for 10 minutes, scrub with a doodlebug equipped with a white or red plastic pad or a disk machine equipped with a white or red plastic pad. If the contamination is stubborn, the HMK R187 Peeling cleaner can be added during scrubbing. Vacuum the residue with a water vacuum! Well after rinsing with clean water, also vacuum this water with a water cleaner. Consumption; approximately 20 m<sup>2</sup> per liter.

### To maintain:

Maintenance can be subdivided into daily/weekly and periodic cleaning. For daily/weekly maintenance, use the HMK P315 Porcelanato maintenance cleaner. Approximately 10 ml. (= 1 cap) mix with 10 liters of lukewarm water and mop normally. Periodic cleaning depends, as far as frequency is concerned, on the use of the surface. Periodic cleaning stands for scrubbing the floors and rinsing with water to remove evenly soiled dirt and to refresh the surface. This works well with HMK R157 Intensive tile cleaner, mixing 1:10 with water, soaking for 10 minutes, scrubbing. If the contamination is stubborn, the HMK R187 Peeling cleaner can be added during scrubbing. Take up residue (preferably vacuum with a water vacuum cleaner) and rinse thoroughly with clean water. Also incorporate this residue, preferably also with a vacuum cleaner. Consumption; approximately 20 m<sup>2</sup> per liter.

### Maintenance bathroom:

Maintenance can be subdivided into daily / weekly and periodic cleaning. For daily / weekly maintenance use the HMK R158 Bathroom and shower cabin cleaner. Spray directly from the bottle on the surface to be cleaned, let it act briefly, do not let it dry. Then scrub with a soft scouring pad (white) or soft brush. Rinse thoroughly with clear water. Repeat the treatment if necessary. Periodic cleaning depends, as far as frequency is concerned, on the use of the surface. Periodic cleaning stands for scrubbing floors and walls, rinsing with water to remove even dirt and to refresh the surface. This works well with HMK R159 Tile and Sanitary Cleaner, Pre-grouting wet, mixing 1:10 with water, soaking for 10 minutes, scrubbing with a doodlebug or slider and good after rinsing with clean water. Consumption; approximately 20 m<sup>2</sup> per liter.

Maxus Ceramics  
Wattstraat 19  
NL-3771 AG Barneveld  
Tel. 0342-413414  
[www.maxusceramics.com](http://www.maxusceramics.com)  
info@maxusceramics.com



*The manufacturer/supplier is not liable for direct or indirect consequences due to incorrect application of the products. The only obligation of the manufacturer/supplier is to replace the product that has not been found suitable. It must be determined in advance whether the product to be used is suitable for the intended purpose; this determination is at your own risk.*

MoellerStoneCare Benelux GmbH  
Torenlaan 10A  
NL-2215 RW Voorhout  
Tel. 0252-220222  
[www.moellerstonecare.nl](http://www.moellerstonecare.nl)  
info@moellerstonecare.nl

